Setup WAN:

```
1) Make Connection
 Connect PC - Switch - Router
               1
             Access Point
               PC
                      SmartPhone
             Laptop
2) Configure Router
 config -> IP Address - 10.0.0.1
         port status - on
3) Configure upper PC
 IP - 10.0.0.2
 Default Gateway - 10.0.2.1
4) Configure Lower PC
 for wireless capability -
 Turn PC Down and Change Component and attach WMP300N
 IP - 10.0.0.3
 Default Gateway - 10.0.2.1
5) Access Point -> config ->port 1
 Authentication WEP set WEP key -> 1234567890
6) Lower PC -> Desktop -> PC Wireless
 connect Enter WEP key
7) Laptop
 Turn Power Down remove port and add WPC300N and turn on power
 set IP Address
 Desktop -> PC -> wireless -> Enter WEP key -> connect
8) Smartphone
 config -> wireless0
 Enter SSID Name
```

It should be working Now

Enter WEP key

Images:







